SAILING DIRECTIONS CORRECTIONS

PUB 194 7 Ed 1996 LAST NM 23/00

Page 168—Line 5/L; read:
channel 73, and must report, as follows:
(BA NP 286) 40/00

Page 168—Line 12/L; read:
4. On leaving the VTS area.

The Stockholm VTS covers the N part of Stockholm Skargard and operates in conjunction with Malaren-Landsort (Sodertalje) VTS, which covers the S part and S entrance. (See Sector 7).

It is reported (2000) that all requests for pilotage must be made through either the Sodertalje VTS station (S entrance) or the Stockholm VTS station.
(BA NP 286) 40/00